



Some components may vary in shape and color or not be present. Always follow codes and quantity shown in list. ○ fixed components □ variable components - - - only reference

SPARE PART		
1	R23990000	PIVOT WHEELS KIT (L + R) EDGARD
2	R23991000	KIT NOZZLE HOLDER EDGARD
<div><div></div><div>+</div></div> 3	F00617210	AUTOMATIC NOZZLE SB325_X CAR
4	R23992000	2M DELIVERY HOSE Ø16 EDGARD
5	R23993000	BATTERY KIT EDGARD
6	R23994000	1,5M SUCTION HOSE Ø16+CAN ADAPTER EDGARD
11	R23995000	LARGE FRONT WHEELS (L + R) EDGARD
12	R23996000	COMPLETE KIT ELECTRONIC + BUTTON EDGARD
13	R23756000	GROUP DIAPHRAGM PUMP 24V DC Low pressure
14	R15275000	15A FUSE W\HOLDER

SPARE PART		
1	R23990000	PIVOT WHEELS KIT (L + R) EDGARD
2	R23991000	KIT NOZZLE HOLDER EDGARD
<div><div></div><div>+</div></div> 3	F00617210	AUTOMATIC NOZZLE SB325_X CAR
4	R23992000	2M DELIVERY HOSE Ø16 EDGARD
5	R23993000	BATTERY KIT EDGARD
6	R23994000	1,5M SUCTION HOSE Ø16+CAN ADAPTER EDGARD
11	R23995000	LARGE FRONT WHEELS (L + R) EDGARD
12	R23996000	COMPLETE KIT ELECTRONIC + BUTTON EDGARD
13	R23756000	GROUP DIAPHRAGM PUMP 24V DC Low pressure
14	R15275000	15A FUSE W\HOLDER